

19.2 Index

<SWCT>_MemMap.h	363	AtomicSwComponentType	129
A2L	370	AUTOSAR Interface	30
Access Point	234, 260	AUTOSAR Methodology	27
Adc	35, 38	AUTOSAR Package	39
Addressing Method	323	AUTOSAR Service	30, 132, 218, 274
alignment	48	AUTOSAR Signal	133, 346, 348, 352
ALIGNMENT	363	AUTOSAR standard elements	39
aliveTimeout	186, 287	AUTOSAR System Description File	28
API functions	314	AUTOSAR System.arxml	28
Application Data Level	52	AUTOSAR tools	28
Application Error	88	AUTOSAR_Platform	39
Application Header File	319	AutosarDataPrototype	52, 94
Application Layer	32	AutosarDataType	223
Application Mode Manager	342	AutosarEngineeringObject	278
Application Software Component	130	AutosarParameterRef	103
Application Types Header File	320	AutosarVariableRef	102
ApplicationArrayDataType	69	BackgroundEvent	306, 323
ApplicationArrayElement	68	Base Type Level	89
ApplicationCompositeElementDataPrototype	95	BaseType	126
ApplicationDataType	45, 52	Basic Software	32
ApplicationError	168	Basic Software Description	317
ApplicationPrimitiveDataType	54	Basic Software Executable Entity	352
ApplicationRecordDataType	67, 175	Basic Software Mode Manager	342
ApplicationSwComponentType	130	Basic Software Module	32
ApplicationValueSpecification	123, 124	Basic Software Module Description	38
argument	167	Basic Software Scheduler	283, 314
ArgumentDataPrototype	96, 160, 162	BITFIELD_TEXTTABLE	107
ARObject	39	bitPosition	49
ARPackage	39	Block Data Mapping	147
ARRAY	53, 68, 72, 75	BLUEPRINT	39
Array Implementation Data Type	75	Boolean	62
arraySizeSemantics	68	BOOLEAN	53, 62
ArrayValueSpecification	122	BSW Mode Manager	33, 36
ARText	43	BswM	33, 36
arTypedPerInstanceMemory	268	BSWM	32
ARXML	32, 43	BSWMD	38
ASAM FSX	153	BswModuleEntity	352
Assembly Connector	151	bswResolution	173
AssemblySwConnector	151	C/S-Port	165
asynchronous	302	Calibration	54, 147, 369
Asynchronous Client-Server Communication	170	calibration data	202
asynchronous communication	166, 174	Calibration Parameter	101
asynchronous mode switching	344	Calibration Parameter Software Component	147
AsynchronousServerCallPoint	170, 234, 245, 247	CalibrationParameterValue	120
AsynchronousServerCallResultPoint	234, 247, 302	CalibrationParameterValueSet	120
AsynchronousServerCallReturnsEvent	168, 247, 256, 302	CalibrationSupportEnabled	369
AsynchronousServerResultCall	170	call queue	170
Atomic Software Component	128	callback	351
		Can	35, 38

CAN Driver	38	component type symbol	129
CAN Interface.....	34, 38	composite data structure	175
CAN Network Management.....	33, 37	Composition Software Component	148
CAN State Manager	33, 37	CompositionSwComponentType	149, 212
CAN Transceiver Driver	34, 38	compound primitive type	123
CAN Transport Layer.....	33, 37	Compu.....	107
canBeInvokedConcurrently	227, 322	compuDefaultValue	107
canEnterExclusiveArea.....	265	compuInternalToPhys.....	103, 107
CanIf.....	34, 38	CompuMethod.....	103, 104, 126
CanNm	33, 37	compuPhysToInternal.....	103, 107
CanSM.....	33, 37	CompuScale	107, 108
CanTp	33, 37	Computation	107
CanTrcv	34, 38	Computation Method	103, 107
Category 1 Runnable Entity	224	Computation Scale.....	107, 108
Category 2 Runnable Entity	224	ComSpec	164
CDD	35, 137	concurrent	265
Chapter	153	configure system.....	28
client	165, 168	Connector	151
Client Port.....	165	CONST	362
ClientComSpec.....	169	Constant value	117
Client-Server Interface.....	166	constantMemory	101, 270
ClientServerAnnotation	172	ConstantReference	125
ClientServerInterface.....	166	ConstantSpecification	117
ClientServerInterfaceMapping	160	ConstantSpecificationMapping.....	118
ClientServerOperation ...	160, 168, 170, 245, 246, 247	ConstantSpecificationMappingSet.....	118
Code.....	278	CONSTP2CONST	361
Code Descriptor	278	CONSTP2VAR	361
codeDescriptor	278	Contract Phase.....	29, 316
Com.....	33, 37	Control Port	375
COM.....	33, 44	Core Test.....	35, 36
COM Manager.....	33, 36	CoreTst.....	35, 36
COM_AXIS.....	53, 63	CPU_BIT_ORDER	87
ComInitValue	189	CPU_BYTE_ORDER	87
ComM	33, 36	CPU_TYPE.....	87
Communication Driver.....	35, 38	CPU_TYPE_16.....	87
Communication HW Abstraction.....	34, 38	CPU_TYPE_32.....	87
Communication Manager	342	CPU_TYPE_8.....	87
communication matrix.....	28, 315	Crypto Service Manager	33, 36
communication needs	164	CseCodeType.....	50
communication paradigms	44	Csm	33, 36
Communication Services	33, 37	CURVE	53, 65, 123
Communication Specification.....	164	cyclic.....	259
Communication Stack.....	37	Data Constraint.....	112
Compatibility Mode	314	data handle	319
Compiler.....	279	Data Type Mapping.....	92
compiler abstraction.....	360	DATA_REFERENCE.....	72, 82
Compiler.h	360	DataConstr	112, 182
Complex Device Driver.....	31, 35, 137, 346	dataElement.....	175, 178, 179, 182
Complex Device Driver Component.....	281	DataFilter	187
ComplexDeviceDriverSwComponentType.....	138, 281	DataFilterTypeEnum	188

dataId.....	380	ECU Extract	28, 72, 277, 316
DataInterface.....	162	ECU hardware.....	346
DataPrototypeMapping.....	162	ECU Resource Description	134
dataReadAccess.....	234	ECU Signal	346, 352
DataReceivedEvent	256, 284	ECU State Manager.....	33, 36, 342
DataReceiveErrorEvent	179, 186, 287	EcuAbstractionSwComponentType136, 172, 281, 348, 351	
dataReceivePointByArgument	234	ECU-C.arxml.....	28
dataReceivePointByValue	234	EcucVariationResolver.....	339
DataSendCompletedEvent	256, 290, 292	EcuM.....	33, 36
dataSendPoint	180, 234, 290	Eep.....	35, 37
DataTypeMap	92	EEPROM.....	35, 37
DataTypeMappingSet.....	92	EEPROM Abstraction	34, 37
dataWriteAccess.....	180, 234, 290	EEPROM Driver	37
DataWriteCompletedEvent	290, 292	enableTakeAddress	273
Dbg	33, 38	enableUpdate	187
Dcm.....	33, 38	endianness.....	52
Debugging.....	33, 38	EndToEndDescription	380
DelegatedPortAnnotation	213	EndToEndProtection.....	379
Delegation Connector	148, 152	EndToEndProtectionSet	379
Delegation Port.....	212	EngineeringObject	278
DelegationSwConnector.....	152	enhancedModeApi	255
Dem	33, 36	enumeration.....	57
Denominator	108	Eth.....	35, 38
DependencyOnArtifact.....	280	Ethernet.....	35
Det	33, 36	Ethernet Driver	38
Development Error Tracer.....	33, 36	Ethernet Interface	34, 38
Device Stack.....	36	Ethernet State Manager	33, 37
Diagnostic Communication Manager.....	33, 38	Ethernet Transceiver Driver	34, 38
diagnostic event	351	EthIf	34, 38
Diagnostic Event Manager	33, 36	EthSM	33, 37
diagnostic information	351	EthTrcv.....	34, 38
Diagnostic Log and Trace.....	33, 36	evaluation order	322
Diagnostic Services.....	33, 36	EXAMPLE.....	39
Dio	35, 38	ExclusiveArea.....	265, 268
direction	97	execution order	322
disabledMode.....	256, 312, 342	explicit	234, 239, 260
displayFormat.....	48, 103	explicit communication	198, 290
DisplayFormatString.....	48	Explicit Read	260
Dlt	33, 36	explicit sender-receiver transmission	180
driver	35	Explicit Write	260
E_NOT_OK.....	89	ExplicitInterRunnableVariable.....	260
E_OK	89	external Trigger	208
E2E profile	380	externalReplacement	185
Ea34, 37		ExternalTriggeringPoint.....	234, 255, 308
ECU Abstraction.....	136, 346, 348, 351	ExternalTriggerOccurredEvent	207, 255, 308
ECU Abstraction Layer	34	failureMonitoring	173
ECU Abstraction Software Component	136, 281	FALSE	87
ECU Configuration	32, 277, 283	Fee	34, 37
ECU Configuration Description.....	28, 314	filter	187
ECU Configuration Variant	326		

filteringDebouncing	174	HIGH_BYTE_FIRST	87
FiM	33, 36	HwAttributeValue	354
FIXED_LENGTH	90	HwCategory	359
Flash	35, 37	HwElement.....	355
Flash Driver	37	HwElementConnector.....	358
Flash EEPROM Emulation	34, 37	HwPin	357
Flash Test	35, 37	HwPinGroup.....	357
flattened	148	HwType	134, 355
FlexRay	35	I/O Driver	35, 38
FlexRay AUTOSAR Transport Layer	33, 37	I/O Hardware Abstraction.....	136, 346
FlexRay Driver	38	I/O HW Abstraction.....	34, 38
FlexRay Interface	34, 38	I/O-Hardware Stack	38
FlexRay ISO Transport Layer	33, 37	ICS	39
FlexRay Network Management	33, 37	Icu.....	35, 38
FlexRay State Manager	33, 37	IDENTICAL	106
FlexRay Transceiver Driver	34, 38	Identifiable	39
Fls	35, 37	Immediate Infrastructure Error	88
FlsTst	35, 37	Implementation	279
Fr 35, 38		Implementation Conformance Statement	39
FrArTp	33, 37	Implementation Data Level	72
FrIf	34, 38	Implementation Policy.....	115
FrNm	33, 37	ImplementationDataType.....	72, 73, 81
FrSM.....	33, 37	ImplementationDataTypeElement	75, 78, 79
FrTp	33, 37	implicit	234, 239, 260
FrTrcv	34, 38	implicit communication	198, 290
FUNC	360	Implicit Read	260
FUNC_P2CONST	360	implicit sender-receiver transmission	180
FUNC_P2VAR	360	Implicit Write	260
Function Inhibition Manager	33, 36	implicit write access.....	323
FUNCTION_REFERENCE	72, 84	ImplicitInterRunnableVariable.....	260
functionPointerSignature	84	in 97	
fundamental dimensions.....	111	IN167	
General Purpose Timer Driver	36	IN/OUT	167
generatedArtifact	279	IncludedDataTypeSet.....	223
Gpt	35, 36	indirectAPI.....	273
handleInvalid	179	Infrastructure Error.....	88
handleNeverReceived.....	188	INIT_POLICY	363
handleOutOfRange	182, 185	initial value.....	100, 119
handleOutOfRangeStatus	186	initialMode.....	294, 342
handleTerminationAndRestart	220	initValue100, 119, 164, 179, 181, 182, 188, 203, 204, 260, 314, 320	
handleTimeoutType.....	189	inout.....	97
Hardware Attribute Value	354	instance.....	154, 222, 267
Hardware Category.....	359	Instance Handle	221, 222
Hardware Connection.....	358	instantiate	154
Hardware Element.....	355	instantiation.....	94, 220
Hardware Pin	357	InstantiationDataDefProps	52
Hardware Pin Group	356	Integration Step	28
hardware protection.....	351	Integrator	28, 29
Hardware Type	354	Inter OS-Application Communication	378
hardwareElement	136		

Inter Runnable Communication	310	Linear conversion	106
Inter-Core communication	44, 376	LinIf	34, 38
Inter-ECU communication	44	Linker	279
Interface	156	LinNm.....	33, 37
Internal Behavior	219	LinSM.....	33, 37
Internal Constraint	112	LinTrcv	34, 38
internal to physical	103	literalPrefix	223
Internal Trigger	255, 310	longName	42
InternalConstrs.....	113, 126	LOW_BYTE_FIRST	87
InternalTriggeringPoint	255, 267, 310	lowerLimit.....	126, 223
InternalTriggerOccurredEvent.....	255, 266, 310	LSB_FIRST.....	87
Inter-Partition communication.....	44	M0.....	30
InterpolationRoutine	50	M1.....	30
Interrunnable Variable	260	M2.....	30
Inter-Task Communication	44	M3.....	30
intervalType.....	115	MAP	53, 66, 123
Intra-ECU communication	44	mapping.....	158
Intra-Partition Communication	44	maxDeltaCounterInit	186
Intra-Task Communication	44	maxNumberOfElements	68
Invalid signal	287	MCAL	34, 346, 348, 351
Invalid value.....	121	McDataInstance.....	280
invalidate	179	mcSupport	280
InvalidationPolicy	179	McSupportData	280, 370
invalidValue	121, 126, 179, 182	Mcu.....	35, 36
IOC	44, 376, 378	Measurement	369
IoHwAb_<ServiceComponentName>_Dcm.h	352	MemIf	34, 37
IoHwAb_Cbk.h.....	351	MemMap	365
IoHwAb_Dcm.....	352	MemMap.h.....	362, 363
IoHwAb_Dcm_Read.....	352	MemMapAddressingMode.....	366
IoHwAb_GetVersionInfo	353	MemMapAddressingModeSet	365
IoHwAb_Init.....	353	MemMapAddressingModeSetRef	367, 368
IoHwAbstraction.....	172	MemMapAddressingModeStart.....	367
IoHwAbstractionServerAnnotation	173	MemMapAddressingModeStop	367
IoHwAbVersionInfoApi	353	MemMapAlignmentSelector	367
IPDU Multiplexer	33, 37	MemMapAllocation.....	367
IpduM	33, 37	MemMapGenericMapping	367
ISO-OSI model layers	36	MemMapMemorySectionRef.....	368
isService	156	MemMapSectionSpecificMapping	367
J1939Tp	33, 37	MemMapSupportedAddressingMethodOption	365
last-is-best semantic.....	189	MemMapSupportedMemoryAllocationKeywordPolic y	365
least	86	MemMapSupportedSectionInitializationPolicy.....	366
library functions	36	MemMapSupportedSectionType	366
Limit.....	115	MemMapSwAddressMethodRef.....	367
Lin	35, 38	Memory Abstraction Interface	34, 37
LIN Driver	38	Memory Allocation Keyword.....	324
LIN Interface	34, 38	Memory Driver	35, 37
LIN Network Management	33, 37	Memory HW Abstraction.....	34, 37
LIN State Manager	33, 37	Memory Management Stack	37
LIN Transceiver Driver	34, 38	Memory Mapping.....	324, 362
LINEAR	106		

Memory Mapping Header	323	Numerator	108
memory section	323	NumericalValueSpecification	122
Memory Section Initialization	324	NvBlock	147
Memory Services	33, 37	NVBlock Software Component	142, 204
MemoryAllocationKeywordPolicyType	324	NvBlockDataMapping	147
MemorySection	324, 325	NvBlockDescriptor	146
MemorySectionType	324	NvBlockNeeds	146
Microcontroller Abstraction Layer	34	NvBlockSwComponentType	143, 204
Microcontroller Driver	35	NvDataInterface	204
Microcontroller Drivers	36	NvDataPortAnnotation	206
Microcontroller Unit Driver	36	NvM	33, 37
minimumStartInterval	226	NvMAdmin	142
Mode	340	NvMNotifyInitBlock	142
Mode Manager	139, 210, 255, 342	NvMNotifyJobFinished	142
Mode Request Type Mapping	92	NvMService	142
Mode Requester	343	NvProvideComSpec	205
Mode Switch Port	294, 340	NVRAM block	268
Mode Transition Value	341	NVRAM Manager	33, 37, 142
Mode User	210, 255, 342	NvRequireComSpec	205
ModeAccessPoint	234, 255	Onboard Device Abstraction	34, 36
ModeDeclarationGroup	161, 340	onEntry	342
ModeDeclarationGroupPrototype	161, 340	onExit	342
ModeInterfaceMapping	161	onTransition	342
Modeling Level	30	onTransitionValue	341
ModePortAnnotation	212	OP_GET	133, 348
ModeRequestTypeMap	92	OP_SET	133, 348
ModeSwitchAckEvent	297, 340	Operating System	33, 36
ModeSwitchedAckEvent	256	operation	166, 167, 168, 170, 172
ModeSwitchInterface	210	OperationInvokedEvent	170, 300
ModeSwitchPoint	234, 255, 297	optimized AUTOSAR Data Type	86
ModeSwitchReceiverComSpec	212	OS	33, 36, 321
ModeSwitchSenderComSpec	211	OsAlarm	323
MSB_FIRST	87	OsScheduleTableExpiryPoint	323
multi-core	44, 376	OsTask	321
multi-dimensional array	77	out	97
MultidimensionalTime	50	OUT	167
MultilanguageReferrable	42	out-of-range	182, 186
multiple instantiation	220, 222, 267, 268	out-of-range handling	185
nativeDeclaration	90	Overlaid Error	88
Network Management	37	P2CONST	361
Network Management Interface	33, 37	P2FUNC	361
Nm	33, 37	P2VAR	361
NonqueuedReceiverComSpec	184	Parameter Port	203
NonqueuedSenderComSpec	181	Parameter Port Interface	202
Non-volatile Block Descriptor	146	Parameter Software Component	147, 202
nonvolatile data	142	ParameterAccess	234, 254
Nonvolatile Data Port Interface	204	ParameterDataPrototype	101, 162, 270
Nonvolatile Data Port Prototype	204	ParameterInterface	202
nonvolatile memory	37	ParameterPortAnnotation	203
numberOfBits	49	ParameterProvideComSpec	203

ParameterRequireComSpec	203	queue.....	170, 254
ParameterSwComponentType	147, 202	queued.....	189, 194, 196, 256, 267, 284
Partial linear conversion.....	106	QueuedReceiverComSpec	184
Partition.....	44, 220, 378	QueuedSenderComSpec.....	181
PDU Router.....	33, 37	queueLength.....	170, 189, 246, 344
PduR	33, 37	RAM block.....	205
Per Instance Memory	268	RAM Test	35, 37
PerInstanceMemory.....	269	RamTst.....	35, 37
PerInstanceParameter.....	267	RAT_FUNC	106
periodic.....	259	readLocalVariable	234, 260
periodically	304	Receiver Port	174
peripherals.....	34, 36, 38	ReceiverComSpec	183
PhysConstrs	113, 126	receive-timeout	189
Physical Constraint	112	Record Layout.....	116
Physical Dimension.....	111	RecordValueSpecification.....	123
physical to internal.....	103	Redefinition Implementation Data Type	81
physical value	133	reentrancy	221
PhysicalDimension.....	111	ReferenceValueSpecification.....	125
PIM	268	Referrable	40
platform.....	86	requiredArtifact.....	280
Platform Type	74, 85	requiredGeneratorTool	280
Platform Type Definition	85	RES_AXIS.....	53, 64
Platform_Types.h	85, 86	ResourceConsumption	281
pointer	82	RoleBasedDataAssignment.....	276
Pointer Implementation Data Type.....	82	RoleBasedPortAssignment	276
Port	35, 38, 155	ROM block	205
Port Interface Mapping Set	158	Root Software Composition	149
PortAPIOption	273	r-port	155
PortGroup.....	214	RPort.....	155
PortHandle.....	273	RPortPrototype.....	155
PortInterface	156	RTE	32, 283, 321
PortInterfaceMapping.....	157, 158	RTE Configuration.....	317
PortInterfaceMappingSet.....	158, 159	RTE Configuration Header File.....	321
PortPrototype.....	155	RTE Data Handle Types Header File	319
possibleError	168	RTE Generation Phase	317
PostBuild Data Set Generation Phase	318	RTE Generator	314
PostBuildVariantCriterionValue	372	RTE Post Build Variant Sets.....	318, 321
PostBuildVariantCriterionValueSet	372	RTE Types Header File	74, 75, 78, 80, 81, 82, 319
p-port.....	155	Rte.c.....	321
PPort.....	155	Rte.h	319
PPortPrototype.....	156	Rte_<SwComponentTypeShortName>.h	319
PreBuild	339	Rte_<SwComponentTypeShortName>_Type.h	320
PreBuild Data Set Generation Phase	318	Rte_ApplicationError.....	88
PredefinedVariant	372	Rte_Call.....	246
PredefinedVariantRef.....	339	Rte_CData.....	267, 272
Primitive Implementation Data Type	74	Rte_Cfg.h	321
printf.....	48	Rte_Core<CoreID>.c	321
prototype.....	94	Rte_DataHandleType.h	319
pulseTest	174	RTE_E_COM_STOPPED.....	89
Pwm.....	35, 38	RTE_E_IN_EXCLUSIVE_AREA	89

RTE_E_INVALID	89, 179	RteBswExclusiveAreaImpl	328
RTE_E_LIMIT	89, 170, 189, 196, 254, 267, 344	RteBswExclusiveAreaOsResourceRef	328
RTE_E_LOST_DATA	89, 189	RteBswExclusiveAreaRef	328
RTE_E_MAX_AGE_EXCEEDED	89, 186	RteBswExternalTriggerConfig	328
RTE_E_NEVER_RECEIVED	89, 188	RteBswGeneral	326
RTE_E_NO_DATA	89, 189	RteBswImmediateRestart	326
RTE_E_OK	89	RteBswImplementationRef	326
RTE_E_SEG_FAULT	89	RteBswInternalTriggerConfig	328
RTE_E_TIMEOUT	89, 170, 255	RteBswMappedToTaskRef	327
RTE_E_TRANSMIT_ACK	89	RteBswModuleConfigurationRef	326
RTE_E_UNCONNECTED	89, 214	RteBswModuleInstance	326
Rte_Enter	265	RteBswPositionInTask	327
Rte_Exit	265	RteBswProvidedModeGroupRef	329
Rte_Feedback	290	RteBswProvidedModeGrpModInstRef	329
Rte_HasOverlaidError	88	RteBswReleasedTriggerModInstRef	329
Rte_Hook.h	320	RteBswReleasedTriggerRef	329
Rte_IrTrigger	267, 310	RteBswRequiredModeGroupConnection	329
Rte_IrvIRead	260	RteBswRequiredModeGroupRef	329
Rte_IrvIWrite	260	RteBswRequiredTriggerConnection	329
Rte_IrvRead	260	RteBswRequiredTriggerRef	329
Rte_IrvWrite	260	RteBswTriggerSourceQueueLength	328
Rte_IsInfrastructureError	88	RteBswTriggerSourceRef	328, 329
Rte_IStatus	287	RteBswUsedOsAlarmRef	327
Rte_IsUpdated	187	RteBswUsedOsEventRef	327
Rte_Mode	255, 343, 344	RteBswUsedOsSchTblExpiryPointRef	327
RTE_MODE	341	RteBypassSupportEnabled	338
Rte_ModeType	341	RteCalibrationSupport	330
Rte_NPorts	273	RteCalibrationSupportEnabled	338
Rte_PBCfg.h	321	RteCalibrationSwAddrMethodRef	338
Rte_PortHandle	273	RteCodeVendorId	330
Rte_Ports	273	RteCoherentAccess	331
Rte_Read	188	RteComponentTypeCalibration	338
Rte_ReadHook	320	RteComponentTypeRef	338
Rte_Receive	284	RteDevErrorDetect	330
Rte_Result	246, 247, 302	RteDevErrorDetectUninit	330
Rte_Switch	255, 343, 344	RTEEvent	283
Rte_SwitchAck	255, 343, 344	RteEventRef	335
RTE_TRANSITION	341	RteEventToTaskMapping	322, 334
Rte_Trigger	208	RteExclusiveAreaImplementation	336
Rte_Type.h	319	RteExclusiveAreaImplMechanism	265, 328, 336
RTE_VERSION_CHECK_FOREIGN_MODULE	321	RteExclusiveAreaOsResourceRef	336
RTE_VFB_TRACE	321	RteExclusiveAreaRef	336
Rte_WriteHook	320	RteExpectedActivationOffset	333
RteActivationOffset	334	RteExpectedTickDuration	333
RteActivationOsAlarmRef	333	RteExternalTriggerConfig	255, 337
RteActivationOsSchTblRef	333	RteGeneration	330
RteActivationOsTaskRef	333	RteGenerationMode	330
RteBswActivationOffset	326	RteImmediateBufferUpdate	331
RteBswEventRef	326	RteImmediateRestart	335
RteBswEventToTaskMapping	326	RteImplementationRef	338

RteImplicitCommunication.....	331	Runtime Environment	32, 283
RteInitializationBehavior	332	SAE J1939 Transport Layer	33, 37
RteInitializationStrategy	332	SCALE_LINEAR	106
RteInternalTriggerConfig	255, 338	SCALE_LINEAR_AND_TEXTTABLE	106, 163
RtelocInteractionReturnValue.....	330, 378	SCALE_RAT_FUNC.....	106
RteMappedToTaskRef	323, 335	SCALE_RATIONAL_AND_TEXTTABLE	107
RteMeasurementSupport.....	330, 369	SchM	314
RteModeScheduleTableRef.....	333	scope.....	238
RteModeSchtblMapBsw	334	sectionInitializationPolicy	314
RteModeSchtblMapBswInstanceRef.....	334	SectionInitializationPolicyType.....	324
RteModeSchtblMapBswProvidedModeGroupRef	334	Sender Port.....	174
RteModeSchtblMapModeDeclarationRef.....	333	SenderComSpec.....	181
RteModeSchtblMapSwc	333	Sender-Receiver Port.....	174, 181
RteModeSchtblMapSwcInstanceRef	334	Sender-Receiver Port Interface	178
RteModeSchtblMapSwcPortRef.....	334	SenderReceiverAnnotation	197
RteModeToScheduleTableMapping.....	333	SenderReceiverInterface	178
RteNvmBlockRef.....	337	sensorActuator	134
RteNvmRamBlockLocationSymbol	337	Sensor-Actuator Software Component	133, 354
RteNvmRomBlockLocationSymbol	337	Sensor-Actuator SW-C.....	348
RteNvRamAllocation	337	SensorActuatorSwComponentType134, 172, 348, 354	
RteOptimizationMode.....	314, 330	server.....	165, 168
RteOsInteraction	333	Server Port.....	165
RteOsSchedulePoint	323, 327, 335	server queue.....	170
RtePositionInTask	322, 335	serverArgumentImplPolicy	98
RtePostBuildUsedPredefinedVariant	339	ServerCallPoint	234, 245, 255
RtePostBuildVariantConfiguration	339	ServerComSpec.....	169, 170
RteSchMVersionInfoApi	326	Service	218
RteSectionInitializationPolicy	332	Service Layer.....	33
RteSoftwareComponentInstanceRef.....	332, 334	Service Port Interface	156
RteSwComponentInstance	334	Service Proxy Software Component.....	139
RteSwComponentType.....	338	Service Software Component.....	132
RteSwcTriggerSourceRef	337, 338	serviceKind	156
RteSwNvRamMappingRef	337	serviceNeeds	275
RteToolChainSignificantCharacters	331	ServiceProxySwComponentType.....	140, 210, 344
RteTriggerSourceQueueLength	208, 267, 337, 338	ServiceSwComponentType.....	132
RteUseComShadowSignalApi	326	SharedParameter.....	267, 270, 272
RteUsedOsActivation.....	333	Short Name.....	40
RteUsedOsAlarmRef.....	336	shortName	40
RteUsedOsEventRef	336	SI Unit	109, 111
RteUsedOsSchTblExpiryPointRef.....	336	signalFan	213
RteValueRangeCheckEnabled	331	SoAd.....	33, 37
RteVariableReadAccessRef.....	332	Socket Adaptor	33, 37
RteVariableWriteAccessRef.....	332	software application.....	130
RteVfbTraceClientPrefix	331	Software Architect.....	29
RteVfbTraceEnabled.....	331	Software Component	127
RteVfbTraceFunction.....	331	Software Component Description.....	29, 32, 316
RteVirtuallyMappedToTaskRef.....	323, 336	Software Component Implementation	277
Runnable.....	223	Software Component Internal Behavior	219
RunnableEntity	223, 224, 352	Software Component Prototype	154
runsInsideExclusiveArea	265		

Software Components Description.....	317	SwImplPolicy.....	115
Software Composition	148	swInterpolationMethod.....	50
Spi	35, 38	swPointerTargetProps	82
SPI Driver	38	swRecordLayout.....	116
STANDARD	39	SwRecordLayoutGroup	116
Standard Symbol.....	89	SwRecordLayoutV	117
Standard Type.....	87	SwSystemconst	373
Standardized AUTOSAR Interface.....	30, 132, 218	SwSystemconstantValueSet	373
Standardized Interface	30	SwSystemconstValue	373
State Management	37	SwTextProps	60
static variables	268	SwVariableRefProxy.....	49
StaticMemory	271	SymbolProps	129
StbM.....	33, 36	Synchronized Time-Base Manager	36
STD_ACTIVE	89	Synchronous Client-Server communication	169
STD_HIGH.....	89	synchronous communication.....	166
STD_IDLE	89	synchronous mode switching	344
STD_LOW	89	SynchronousServerCallPoint.....	245
STD_OFF.....	89	SynchronousServerCallPoint.....	169, 234
STD_ON.....	89	SynchronousServerCallPoint.....	246
Std_ReturnType	87	System Configuration Description	28, 316
Std_Types.h	87, 89, 319	System Configuration Input	28
Std_VersionInfoType	87, 353	System Extract	316
strictConfigurationCheck	314	System Level	27
strictInitialValuesCheck	314	System Services.....	33, 36
strictUnconnectedRPortCheck.....	213, 314	system signals	315
STRING	53, 59	System Stack	36
STRUCTURE	53, 67, 72, 78	TAB_NOINTP	107
Structure Implementation Data Type.....	78	Task.....	321
supportsAsynchronousModeSwitch.....	344	TEXTTABLE	106, 163
supportsMultipleInstantiation.....	154, 220, 222, 227, 267	TextTableMapping	163
SwAddrMethod.....	324	TextualValueSpecification.....	121
swAlignment	48	timeout	245, 247, 255, 290, 302
swBaseType	89, 90	TimingEvent	259, 304, 323
SwBitRepresentation	49	Top-level Composition.....	149
SW-C	127	transmissionAcknowledge	183, 290
swCalibrationAccess	369	Transport Layers	37
SwcBswMapping.....	281, 282, 353	Trigger.....	161, 209, 266, 308
SWCD	32, 316	Trigger Port Interface.....	207
SwcImplementation.....	277	Triggering.....	310
SwcInternalBehavior.....	219, 224	TriggerInterface	207, 308
SwcModeSwitchEvent	256, 295, 340	TriggerInterfaceMapping.....	161
SwComponentDocumentation	153	TriggerPortAnnotation.....	209
SwComponentPrototype	154	TRUE.....	87
SwComponentType.....	127	Ttcan	35, 38
SwConnector.....	151, 158	TTCAN Driver.....	38
SwcServiceDependency	275	TTCAN Interface	34, 38
SwDataDefProps	45, 95	TtcanIf	34, 38
SwDataDependency.....	51	TYPE_REFERENCE.....	72, 81
swHostVariable	49	typedef.....	72
		typeDefinition	270

typeEmitter.....	319	VariationPoint.....	371
UDP Network Management	33, 37	vehicle mode	139
UdpNm	33, 37	vehicle network communication	37
Unconnected Port	214	Vehicle Network System.....	37
unconnected R-Ports.....	314	vertical stack.....	36
union.....	79	VFB.....	42, 43, 283
UNION.....	72, 79	VFB level	32
Union Implementation Data Type	79	VFB Tracing Header File.....	320
Unit	103, 109	VFC.....	375
UnitGroup.....	110	VFC Controller	375
upperLimit	126, 223	VFC Status Port	375
useArgumentType	98	Virtual Function Cluster.....	375
useArrayType	98	Virtual Functional Bus.....	27, 42, 43, 283
UsedOsEventRef.....	323	WaitPoint.....	247, 256, 283, 284, 290, 297, 302
useVoid.....	98	Watchdog	35
VAL_BLK.....	53, 61	Watchdog Driver	36
VALUE	53, 54, 72, 74	Watchdog Interface.....	34, 36
Value Block	61	Watchdog Manager.....	33, 36
ValueSpecification	121	Wdg	35, 36
VAR	362	WdgIf	34, 36
VARIABLE_LENGTH.....	90	WdgM	33, 36
VariableAccess.....	239	writtenLocalVariable	234, 260
VariableAndParameterInterfaceMapping.....	162	Xcp	33, 37
VariableDataPrototype.....	100, 162	XCP.....	33, 370

19.3 Table Reference

Figure 2-1 Methodology Overview (source: AUTOSAR.org)	27
Figure 2-2 Interface Types of Basic Software (source: AUTOSAR.org).....	29
Figure 4-1 Software Components on VBF View	43
Figure 4-2 Software Components on RTE	43
Figure 5-1 Application Data Type (source: AUTOSAR.org).....	53
Figure 5-2 5.4.1 Compatibility of Implementation Data Types.....	74
Figure 5-3 DataTypeMappingSet (source: AUTOSAR.org).....	93
Figure 5-4 Data Prototypes (source: AUTOSAR.org)	95
Figure 5-5 CompuMethod (source: AUTOSAR.org).....	104
Figure 5-6 Data Constraints, CompuMethod, BaseType and invalidValue (source: AUTOSAR.org).....	126
Figure 6-1 Software Components (source: AUTOSAR.org)	128
Figure 6-2 Service Proxy on VFB view	140
Figure 6-3 Service Proxy on ECUs	140
Figure 7-1 Client-Server Composition	165
Figure 7-2 Sender-Receiver Communication.....	175
Figure 7-3 Non-deterministic sequence for S/R communication.....	175
Figure 7-4 Queued S/R communication n:1	194
Figure 7-5 Queued S/R communication 1:n	196
Figure 7-6 Sender-Receiver communication example	199
Figure 7-7 Port Groups example	215
Figure 8-1 Asynchronous Client-Server Communication	248
Figure 8-2 Interrunnable Communication.....	261
Figure 9-1 ECU Abstraction Component (source: aurosar.org).....	281